



Linux 3.14.29 Package Release Note Revision 1.0

Amlogic, Inc.
3930 Freedom Circle
Santa Clara, CA 95054
U.S.A.
www.amlogic.com

Legal Notices

© 2014 Amlogic, Inc. All rights reserved. Amlogic ® is registered trademarks of Amlogic, Inc. All other registered trademarks, trademarks and service marks are property of their respective owners.

This document is Amlogic Company confidential and is not intended for any external distribution.

Amlogic Application Notes

Index

1. Overview.....	4
2. Chapter 1: Supported Packages.....	5
2.1 List of Supported Package.....	5
3. Chapter 2: Supported Boards.....	8
3.1 List of Supported Boards.....	8
4. Chapter 3: Linux Compilation and Installation Procedures.....	9
4.1 Toolchains	9
4.2 Compiling the System	9
4.3 Installing Linux on SD Card.....	10
4.4 Installing Linux on EMMC/Nand Flash.....	10
Appendix A: Wi-Fi Enabling Procedures.....	12
Appendix B: Libplayer Test Procedures	13
Appendix C: Mali and QT5 Test Procedures.....	14

Amlogic Application Notes

Revision History

Revision	Date	Author	Changes
1.0	Dec 25, 2015	Matthew Shyu	Release for 3.14/s905

1. Overview

This document describes the packages and features that are supported in Amlogic Linux platforms.

It includes:

- Chapter 1: Supported Packages
- Chapter 2: Supported Boards
- Chapter 3: Linux Building and Installation Procedures
- Appendix A: Wi-Fi Enabling Procedures
- Appendix B: Libplayer Test Procedures
- Appendix C: Mali and QT5 Test Procedures

2. Chapter 1: Supported Packages

Amlogic adopts Buildroot as package management system. See <http://buildroot.uclibc.org/> for more details on how it works.

2.1 List of Supported Package

Package	Version	Description
alsa-lib	1.0.29	ALSA User space library. See http://www.alsa-project.org/
alsa-utils	1.0.29	Command line utilities for the ALSA. See http://www.alsa-project.org/
aml_libs		Amlogic video/audio decoder
aml_nand		Amlogic Nand driver
aml_pmu		Amlogic PMU driver
aml_thermal		Amlogic thermal driver
aml_util	0.1	Utilities
boost	1.58.0	Set of libraries for C++. See http://www.boost.org/
brcmap6xxx		Broadcom wifi driver
busybox	1.24.1	Tiny versions of many common UNIX utilities. See http://www.busybox.net/
cairo	1.14.4	2D graphics library. See http://cairographics.org
cjson	58	ANSI-C compliant JSON parser. See http://sourceforge.net/projects/cjson/
dbus	1.10.2	Message bus system. See http://www.freedesktop.org/wiki/Software/dbus/
dhcpcd	6.9.3	DHCP client daemon. See http://roy.marples.name/projects/dhcpcd/wiki
directfb	1.7.7	Graphics library. See http://www.directfb.org/
e2fsprogs	1.42.13	Filesystem utilities for use with the ext2/3/4 filesystem. See http://e2fsprogs.sourceforge.net/
expat	2.1.0	Library for parsing XML written in C. See http://expat.sourceforge.net/
fbdump	0.4.2	Tools to captures the contents of framebuffer device. See http://www.rcdrummond.net/fbdump/
fbgrab	1.2	Framebuffer screenshot program. See http://freecode.com/projects/fbgrab
fbterm	1.7.0	Framebuffer based terminal emulator. See http://code.google.com/p/fbterm/
fb-test-app	rosetta-1.1.0	Test suite for Linux framebuffer. See https://github.com/prpplague/fb-test-app
fontconfig	2.11.1	Font configuration and customization library. See http://www.freedesktop.org/wiki/Software/fontconfig/
freetype	2.6.1	Fonts rendering library. See http://www.freetype.org
gdb	7.9.1	GNU debugger. See https://www.gnu.org/software/gdb/
gpu		Amlogic Mali gpu driver
harfbuzz	1.0.6	Opentext shaping engine. See http://www.freedesktop.org/wiki/Software/HarfBuzz/
icu	56.1	International Components for Unicode. See http://site.icu-project.org/
iw	4.3	nl80211 based utility for wireless devices. See

Amlogic Application Notes

		http://wireless.kernel.org/en/users/Documentation/iw
kmod	20	Kernel module tools. See https://www.kernel.org/pub/linux/utils/kernel/kmod/
libcurl	7.45.0	Multiprotocol file transfer library. See http://c-ares.haxx.se/
libffi	3.2.1	Event notification library. See http://libevent.org/
libglib2	2.46.1	See https://developer.gnome.org/glib/
libid3tag	0.15.1b	See http://sourceforge.net/projects/mad/files/libid3tag/
libjpeg	9a	Jpeg library. See http://libjpeg.sourceforge.net/
libmad	0.15.1b	MPEG audio decoder. See http://sourceforge.net/projects/mad/
libnl	3.2.27	Libraries for netlink protocol. See http://www.infradead.org/~tgr/libnl/doc/api/
libplayer	2.1.0	Amlogic media player library
libsoup	2.43.1	HTTP client/server library for GNOME. See https://developer.gnome.org/libsoup/
libsvg	0.1.4	Provides a parser for SVG content. See http://cairographics.org/
libsvg-cairo	0.1.6	Provides the ability to render SVG content. See http://cairographics.org/
libxml2	2.9.3	XML toolkit. See http://xmlsoft.org/
libxslt	1.1.28	XSLT support for libxml2. See http://xmlsoft.org/XSLT/
linux-amlogic	3.14.29	Amlogic Linux kernel
mali_examples	2.0.0.9 444	Mali OpenGL ES examples. See http://malideveloper.arm.com/cn/develop-for-mali/sdks/opengl-es-sdk-for-linux/
ncurses	5.9	New curses library. See http://www.gnu.org/software/ncurses/
openssl	1.0.2e	Cryptography library. See http://www.openssl.org/
pango	1.38.1	Library for layout and rendering of text. See http://www.pango.org/
pcre	8.38	Perl compatible regular expression. See http://www.pcre.org/
pixman	0.32.8	Low-level pixel manipulation library. See http://www.pixman.org/
qt5base	5.5.0	Cross-platform application and UI framework. See http://qt-project.org/
qt5imageformats	5.5.0	See http://qt-project.org/
qt5multimedia	5.5.0	See http://qt-project.org/
qt5serialport	5.5.0	See http://qt-project.org/
qt5svg	5.5.0	See http://qt-project.org/
qt5xmlpatterns	5.5.0	See http://qt-project.org/
remotecfg	1.0.0	Amlogic remote configuration tool
rtk8188eu		Realtek 8188EU driver
rtk8189es		Realtek 8189ES driver
rtk8723au		Realtek 8723AU driver
rtk8723bs		Realtek 8723AU driver
sqlite	308110 1	SQL database engine. See http://www.sqlite.org/
tslib	1.1	Abstraction layer for touchscreen panel events. See

Amlogic Application Notes

		http://tslib.berlios.de/
uboot		Amlogic uboot
util-linux	2.27.1	Essential utilities for Linux. See https://www.kernel.org/pub/linux/utils/util-linux/
wavpack	4.75.2	Open audio codec. See http://www.wavpack.com/
wpa_supplicant	2.5	See http://hostap.epitest.fi/wpa_supplicant/
wifi-fw		Wifi DSP firmware
zlib	1.2.8	Data compression library. See http://www.zlib.net/

3. Chapter 2: Supported Boards

This chapter lists the reference boards that Amlogic currently supports.

3.1 List of Supported Boards

Amlogic supports the following reference boards, namely p200, p201, odroidc2 with Linux kernel 3.14.29. This section lists the features and peripherals for these boards.

P200:

- Amlogic S905 CPU
- 1GB DDR3
- HDMI out x 1
- TF Card x 1
- Ethernet x 1
- SDIO Wifi/BT (AP6354) x 1
- ADC key x 1
- YPbPr out x 1
- SPDIF (coaxial) x 1
- USB hub x 1
- USB otg x 1
- EMMC x 1

P201:

- Amlogic S905 CPU
- 1GB DDR3
- HDMI out x 1
- TF Card x 1
- SDIO Wifi (brcm 40183) x 1
- USB hub x 1
- USB otg x 1
- SPI & Nand x 1

Odroidc2:

- Amlogic S905 CPU
- 2GB DDR3
- HDMI out x 1
- TF Card x 1
- USB hub x 1
- USB otg x 1

4. Chapter 3: Linux Compilation and Installation Procedures

4.1 Toolchains

Two sets of toolchains are used in the compilation.

The first one is used for compiling kernel and applications and it is automatically download from Linaro's website by Buildroot. The path is shown below just for completeness.

http://releases.linaro.org/14.09/components/toolchain/binaries/gcc-linaro-aarch64-linux-gnu-4.9-2014.09_linux.tar.xz

The second set of toolchains is used for compiling uboot and it can be downloaded from Amlogic OpenLinux website through

```
wget -c http://openlinux.amlogic.com:8000/deploy/CodeSourcery.tar.gz
wget -c http://openlinux.amlogic.com:8000/deploy/gnutools.tar.gz
wget -c http://openlinux.amlogic.com:8000/deploy/arc-4.8-amlogic-20130904-r2.tar.gz
wget -c
http://openlinux.amlogic.com:8000/deploy/gcc-linaro-aarch64-none-elf-4.8-2013.11\_linux.tar
```

Extract and put them into search path.

```
$ tar xzf CodeSourcery.tar.gz -C /opt
$ tar xzf gnutools.tar.gz -C /opt
$ tar xzf arc-4.8-amlogic-20130904-r2.tar.gz -C /opt
$ tar xf gcc-linaro-aarch64-none-elf-4.8-2013.11_linux.tar -C /opt
$ export PATH=$PATH:
/opt/gnutools/arc2.3-p0/elf32-4.2.1/bin:/opt/gnutools/arc2.3-p0/uclibc-4.2.1/bin:/opt/arc-4.8-amlogic-20130904-r2/bin:/opt/CodeSourcery/Sourcery_G+_Lite/bin:/opt/CodeSourcery/Sourcery_G+_Lite/arm-none-eabi/bin:/opt/CodeSourcery/Sourcery_G+_Lite/arm-none-linux-gnueabi/bin:/opt/gcc-linaro-aarch64-none-elf-4.8-2013.11_linux/bin/
```

4.2 Compiling the System

Getting the source code:

```
$ wget -c
http://openlinux.amlogic.com:8000/download/ARM/filesystem/arm-buildroot-2015-12-25-0
```

Amlogic Application Notes

5d8ead338.tar.gz

Compilation:

```
$ tar zxvf arm-buildroot-2015-12-25-05d8ead338.tar.gz
$ cd buildroot
$ make mesongxb_p200_release_defconfig # For p200 boards
$ make mesongxb_p201_release_defconfig # For p201 boards
$ make mesongxb_amlogic_odroidc2_release_defconfig # For odroidc2 boards
$ make
```

Note: Do not use make -jN here as Buildroot does not support top-level parallel make. This does not mean that Buildroot does not support parallel compilation, but just that it will handle this inside the Buildroot compilation system.

4.3 Installing Linux on SD Card

The following steps show how to install the resulting system on your SD card.

Note: You should use an SD card that is **at least 4GB**.

1. Create an SD card with one partition in ext2 format.
2. Copy boot.img, rootfs.tar.gz to this partition

```
$ sudo cp output/images/boot.img /media/sdcard
$ sudo cp output/images/rootfs.tar.gz /media/sdcard
$ sudo sync
```
3. Extract rootfs.tar.gz on SD card

```
$ cd /media/sdcard
$ sudo tar zxvf rootfs.tar.gz
$ sync
```
4. Write uboot to SD card

```
$ sudo dd if=output/images/u-boot.bin.sd.bin of=/dev/mmcblk0 bs=512
skip=1 seek=1
$ sudo sync
```
5. If there's some old data on the flash, you might wish to erase them all

```
# store init 3
# reset // now the system starts from sd card
```
6. When running into uboot, execute "run bootssdcard" under the prompt:

```
# env default -a
# env save
# run bootssdcard
```

Note: Step 5 and 6 are not needed for odroidc2 since only sd card is supported.

4.4 Installing Linux on EMMC/Nand Flash

Warning! All previous changes will be lost.

1. Create an SD card with one partition in vfat format
2. copy boot.img and root file system to SD card

```
$ cp output/images/u-boot.bin /media/mySD
```

Amlogic Application Notes

```
$ cp output/images/boot.img /media/mySD
```

```
$ cp output/images/rootfs.tar.gz /media/mySD
```

Insert SD card into your platform and reboot into uboot.

Replace original uboot with the new one under uboot prompt:

```
# mmcinfo
```

```
# fatload mmc 0 ${loadaddr} u-boot.bin
```

```
# store rom_write ${loadaddr} 0 100000
```

```
# fatload mmc 0 ${loadaddr} gxbb_p200.dtb (gxbb_p201.dtb) // This step  
writes a valid dtb first
```

```
# store dtb write ${loadaddr}
```

```
# reset
```

3. With new uboot burned on your platform, enter uboot prompt again and execute "run bootupdate"

```
# env default -a
```

```
# env save
```

```
# run bootupdate
```

4. System will automatically write kernel to boot partition and extract rootfs.tar.gz to system partition.
5. Reboot platform.
6. System will boot up with kernel and root filesystem on EMMC/NAND.

Appendix A: Wi-Fi Enabling Procedures

The appendix describes procedures for enabling Wi-Fi on Amlogic Linux platform manually:

- Check module existence:

```
# lsmod
Module          Size Used by  Not tainted
dhd             410618 0
```

If not,

```
# modprobe dhd
```

Note: “dhd” is the driver module name for broadcomm WIFI module. This name may vary depends on different WIFI modules equipped on your platform.

- Set up /etc/wpa_supplicant.conf:

Example:

```
ctrl_interface=/var/run/wpa_supplicant
ctrl_interface_group=0
ap_scan=1
```

```
network={
    ssid="myAP"
    pairwise=CCMP TKIP
    group=CCMP TKIP
    proto=WPA RSN
    key_mgmt=WPA-PSK
    priority=5
    psk="my_passwd"
}
```

- Restart wpa_supplicant:
/etc/init.d/S42wifi reload
or enable wpa_supplicant directly:
wpa_supplicant -B -Dnl80211 -iwlan0 -c/etc/wpa_supplicant.conf
- Enable DHCP client:
dhcpcd
- Put your wpa_supplicant.conf under /board/amlogic/meson_XXX/rootfs/etc/ and regenerate your file system. Next time system will automatically enable Wi-Fi.
Note: Modify meson_XXX according to your platform.
For example: meson_g18 --> g18
meson_k200 --> k200

Appendix B: Libplayer Test Procedures

This appendix demonstrates how to use kplayer to exercise Libplayer. (For non-X platforms only)

Usage: kplayer <file>

- 0 show main menu
- a start play
- s get media info
- 1 Pause play
- 2 Resume play
- 3 Stop play
- 4 Fast forward
- 5 Fast rewind
- 6 Seek
- 7 Set repeat
- 8 Quit tools

Appendix C: Mali and QT5 Test Procedures

Leave Framebuffer sleep mode
echo 0 > /sys/class/graphics/fb0/blank

Mali examples: (For non-X platforms only)

There are a couple Mali execution examples under /usr/share/arm/OpenGL-ES-2.0
For example,

```
# sh /etc/set_display_mode.sh  
# cd /usr/share/arm/OpenGL-ES-2.0/Cube  
# ./Cube
```

QT5 examples:

QT5 demos are located under /usr/lib/qt/examples
For example,

```
# sh /etc/set_display_mode.sh  
# cd /usr/lib/qt/examples/widgets/animation/animatedtiles  
# ./animatedtiles  
# cd /usr/lib/qt/examples/gui/openglwindow  
# ./openglwindow
```